

Dispersal equipment Fans & Atomisers – mobile



Pacific Mobile

Product Aim

The most effective unit of its kind, the Pacific Mobile offers the coverage and quality of a perimeter style system, with the convenience and flexibility of a mobile unit, at an affordable price.

How it works

The Pacific Mobile is trailer mounted and can be taken directly to the source of the problem.

The integral trailer carries a 1125L capacity bowser, which is filled with either dilute *Odr* for odour neutralisation, or water for dust applications. A 100m nozzle line (50m either side) is then deployed on to pig tail stakes (included), around the problem area. With flexible nozzle line, you can tailor the Pacific Mobile system to provide a unique solution, each time it is used.

Diesel powered, the Pacific Mobile provides an industry best coverage, of 100m, which produces a finely atomised mist curtain. This effectively suppresses dust, and with the addition of *Odr*, neutralises odour.

Turnkey operation gives up to 4 hours continuous running on one tank and all fittings are push fit, making the Pacific Mobile convenient and easy to use, delivering effective and affordable mobile odour suppression and dust control.

The Pacific Mobile is available to purchase or at competitive hire rates.

For more information contact:

E: Enquiry@AirSpectrum.com
T: +44(0)1905 362100
F: +44(0)1905 362101



Features

- Highly mobile, with integral trailer
- Trailer mounted 1125L bowser tank, giving 4 hours continuous operation
- 100m of high pressure nozzle line (included)
- 50 high pressure brass Nozzles (included)
- 10m of high pressure manifold (included)
- Push-fit stainless steel fittings
- Available to purchase or hire

Key Information

Fuel: Diesel

Air Spectrum Environmental Limited continually strives to improve its products and therefore reserves the right to introduce modifications to their product range without notice.

www.AirSpectrum.com