

Instructions for use:

These instructions relate to the use of ASE Disinfect (Concentrate) – product reference ASED-CON-V only. 0.4% of super concentrate. This ASE Disinfect (Concentrate) is designed for application via Air Spectrum Environmental spray equipment. Other equipment will have differing flow rates and thus these instructions may not be suitable.

At the recommended dilution ratio of 40:1, One 25 Litre container of ASE Disinfect should be used with a trailer mounted bowser system (1125l) of potable water.

When filling the bowser, personnel should use PPE suitable for the site's HSE. **However when handling this concentrate solution, close-fitting goggles (not normal safety glasses) and chemical resistant gloves should be used at all times.** If guideline dilutions are not followed Air Spectrum Environmental cannot be held responsible for any unforeseen effects.

The building being sprayed should be clear of personnel, during and after application. It is recommended that it is left overnight, or until the mist has cleared and ideally for a minimum of 6 hours, until the spray has settled, and the surfaces are dry.

No contact with surfaces receiving application of the product should be allowed for a similar time frame as mentioned above. Spraying should be for a time dependant on the size of the building but stopped either within one hour or until the building is misted – whichever is the shorter time. No personnel should enter the building during this time.

If you have any further queries please contact our team on 01905 362100 or email us at info@airspectrum.com