

quattro

4-in-1 effective defence



ASE 'quattro' combines 4 effective spray methods to make an all-round effective defence against dust and odour. The quattro unit consists of:

Rainmaker

Extends to a height of 3m, 3 powerful jet nozzles throw mist up to 20m.

Applications: Stationary dust suppression.

Handheld Jet Wash

Lance for controlled spraying area.

Applications: Direct application to problem areas (ideal for applying chemical additives direct to source.)

Rear Spray Bar

Measuring 1.6m in diameter with 10 powerful jet nozzles.

Applications: Damping down roads and tracks.

Nozzle-line attachment

Detachable 10m manifold and T-Section to run 2 X 50m of 2m spaced flexible nozzle-line.

Applications: Boundary suppression system.



Suitable for: Odour, Dust, Disinfection

APPLICATIONS

- Demolition
- Ground Remediation
- Bulk Materials Handling
- Waste Transfer and Landfill
- Crushing and Screening
- Construction
- Mining and Quarrying
- Aggregates
- Disinfection Services
- Manufacturing

TECHNICAL SPECIFICATION

Droplet size (μm) - 50-100 microns

Nozzles (pcs) - Rainmaker (3), Rear Spray Bar (10)

Rainmaker - Extendable 3m mast with 3 high-pressure nozzles

Jetwash - 7m stowed hose with lance

Bowser - Road towable trailer with 1125l tank

Nozzleline - 2 x 50m flexible nozzleline, 2m spaced, 10m manifold fitted with quick release fitting for ease of use

Coupling - Available in 40mm eye or 50mm ball hitch

Spray Bar - Custom spray bar with 10 high pressure nozzles on rear chassis

Power supply - Yanmar L100 engine

All equipment selectable via a simple diverter valve

AVAILABLE TO
PURCHASE OR HIRE

Call us
01905 362100

Chat with us
www.airspectrum.com